

# Fish Catalase (CAT) ELISA kit

Catalog No. CSB-E15928Fh

(96 T)

- This immunoassay kit allows for the in vitro quantitative determination of **fish CAT** concentrations in **serum**, **plasma**.
- Expiration date six months from the date of manuCATcture
- FOR RESEARCH USE ONLY. NOT FOR USE IN DIAGNOSTIC PROCEDURES.

## PRINCIPLE OF THE ASSAY

This employs the competitive inhibition assay immunoassay technique. An antibody specific to CAT has been pre-coated onto a microplate. Standards or samples are added to the appropriate microtiter plate wells with HRP-conjugated CAT and incubated. A competitive inhibition reaction is launched between CAT (Standards or samples) and HRP-conjugated CAT with the pre-coated antibody specific for CAT. The more amount of CAT in samples, the less antibody bound by HRP-conjugated CAT. Then the substrate solutions are added to the wells, respectively. And the color develops in opposite to the amount of CAT in the sample. The color development is stopped and the intensity of the color is measured.

# **DETECTION RANGE**

The standard curve concentrations used for the ELISA's were 2000mU/ml, 1000 mU/ml, 500 mU/ml, 250 mU/ml, 125 mU/ml.

# **SPECIFICITY**

This assay recognizes fish CAT. No significant cross-reactivity or interference was observed.

# **SENSITIVITY**

The minimum detectable dose of fish CAT is typically less than 62.5 mU/ml.

The sensitivity of this assay, or Lower Limit of Detection (LLD) was defined as the lowest protein concentration that could be differentiated from zero.

# **MATERIALS PROVIDED**

Reagent	Quantity
Assay plate	1
Standard	1 x 200µl
	(A solution of 20000 mU/ml)
HRP-conjugate	1 x 60µl
HRP-conjugate Diluent	1 x 10 ml
Sample Diluent	2 x 20 ml
Wash Buffer	1 x 20 ml
	(25×concentrate)
TM Substrate	1 x 10 ml
Stop Solution	1 x 10 ml

# **STORAGE**

- 1. Unopened test kits should be stored at 2-8°C upon receipt and the microtiter plate should be kept in a sealed bag with desiccants to minimize exposure to damp air. The test kit may be used throughout the expiration date of the kit. Refer to the package label for the expiration date.
- 2. Opened test kits will remain stable until the expiring date shown, provided it is stored as prescribed above.
- 3. A microtiter plate reader with a bandwidth of 10 nm or less and an optical density range of 0-3 OD or greater at 450nm wavelength is acceptable for use in absorbance measurement.

# REAGENT PREPARATION

- Bring all reagents and plate to room temperature for at least 30 minutes before use. Unused wells need store at 2-8°C and avoid sunlight.
- Wash Buffer If crystals have formed in the concentrate, warm up to room temperature and mix gently until the crystals have completely dissolved. Dilute 20 ml of Wash Buffer Concentrate into deionized or distilled water to prepare 500 ml of Wash Buffer.

 HRP-conjugate Centrifuge the vial before opening. Dilute to the working concentration using HRP-conjugate Diluent(1:100), respectively.

#### 4. Standard

- Centrifuge the vial before opening. Allow the 20000 mU/ml standard solution to warm to room temperature .Label six tubes#1 through #6.
- Pipette 270µl Sample Diluent into tube#1. Add 30µl of the 20000 mU/ml standard to tube #1. Vortex thoroughly. The 2000 mU/ml standard(tube #1)serves as the high standard.
- Pipette 150µl Sample Diluent into tubes#2-6. Add 150µl of tube #1 to tube #2 and vortex thoroughly ,Add 150µl of tube #2 to tube #3 and vortex thoroughly,Continue this for tubes #3 through 5. Mix each tube thoroughly before the next transfer. Sample Diluent serves as the zero standard (0mU/ml) (tube #6).

The concentration of fish CAT in tubes #1through #6 will be 2000 ,1000 ,500 ,250 , 125 and 0 mU/ml respectively.

Diluted standards should be used within 30 minutes of preparation.

Precaution: The Stop Solution provided with this kit is an acid solution. Wear eye, hand, CATce, and clothing protection when using this material.

## OTHER SUPPLIES REQUIRED

- Microplate reader capable of measuring absorbance at 450 nm, with the correction wavelength set at 540 nm or 570 nm.
- Pipettes and pipette tips.
- Deionized or distilled water.
- Squirt bottle, manifold dispenser, or automated microplate washer.

## SAMPLE COLLECTION AND STORAGE

- Serum Use a serum separator tube (SST) and allow samples to clot for 30 minutes before centrifugation for 15 minutes at 1000 g. Remove serum and assay immediately or aliquot and store samples at -20°C. Centrifuge the sample again after thawing before the assay. Avoid repeated freeze-thaw cycles.
- Plasma Collect plasma using citrate, EDTA, or heparin as an anticoagulant. Centrifuge for 15 minutes at 1000 g within 30 minutes of collection. Assay immediately or aliquot and store samples at -20°C. Centrifuge the sample again after thawing before the assay. Avoid repeated freeze-thaw cycles.

Note: Grossly hemolyzed samples are not suitable for use in this assay.

#### SAMPLE PREPARTION

Recommend to dilute the serum or plasma samples with Sample Diluent(1:200) before test. The recommended dilution CATctor is for reference only. The optimal dilution CATctor should be determined by users according to their particular experiments.

### **ASSAY PROCEDURE**

Bring all reagents and samples to room temperature before use. It is recommended that all samples, standards, and controls be assayed in duplicate.

- 1. Add 50µl of Standard or Sample per well. Standard need test in duplicate.
- 2. Add 50µl of **HRP-conjugate working solution** to each well, Mix well and then incubate for 40 minutes at 37°C.
- 3. Fill each well with Wash Buffer (about 200µl), stay for 10 seconds and Spinning. Repeat the process for a total of five washes. Complete removal of liquid at each step is essential to good performance. After the last wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against clean paper towels.
- 4. Add 90µl of **TMB Substrate** to each well, mix well. Incubate for 20 minutes at 37°C. Keeping the plate away from drafts and other temperature fluctuations in the dark.
- 5. Add 50µl of **Stop Solution** to each well.

6. Determine the optical density of each well within 10 minutes, using a microplate reader set to 450 nm.

## **CALCULATION OF RESULTS**

Average the duplicate readings for each standard, control, and sample and subtract the average zero standard optical density. Create a standard curve by reducing the data using computer software capable of generating a four parameter logistic (4-PL) curve-fit. As an alternative, construct a standard curve by plotting the mean absorbance for each standard on the x-axis against the concentration on the y-axis and draw a best fit curve through the points on the graph. The data may be linearized by plotting the log of the CAT concentrations versus the log of the O.D. and the best fit line can be determined by regression analysis. This procedure will produce an adequate but less precise fit of the data. If samples have been diluted, the concentration read from the standard curve must be multiplied by the dilution CATctor.

# LIMITATIONS OF THE PROCEDURE

- The kit should not be used beyond the expiration date on the kit label.
- Do not mix or substitute reagents with those from other lots or sources.

- If samples generate values higher than the highest standard, dilute the samples and repeat the assay.
- Any variation in operator, pipetting technique, washing technique, incubation time or temperature, and kit age can cause variation in binding.

## **TECHNICAL HINTS**

- When mixing or reconstituting protein solutions, always avoid foaming.
- To avoid cross-contamination, change pipette tips between additions of each standard level, between sample additions, and between reagent additions. Also, use separate reservoirs for each reagent.
- When using an automated plate washer, adding a 30 second soak period following the addition of wash buffer, and/or rotating the plate 180 degrees between wash steps may improve assay precision.
- To ensure accurate results, proper adhesion of plate sealers during incubation steps is necessary.
- Substrate Solution should remain colorless until added to the plate. Keep Substrate Solution protected from light. Substrate Solution should change from colorless to gradations of blue.

 Stop Solution should be added to the plate in the same order as the Substrate Solution. The color developed in the wells will turn from blue to yellow upon addition of the Stop Solution.
Wells that are green in color indicate that the Stop Solution has not mixed thoroughly with the Substrate Solution.